

K RAIN®

KCONNECT

Wi-Fi TAP TIMER KIT

KRB1001W



WWW.K-RAIN.COM.AU

User Manual



iOS is a trademark of Apple Inc. Android is a trademark of Google LLC. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Holman Industries is under license. Other trademarks and trade names are those of their respective owners. All other content is Copyright © Holman Industries 2023.

Product code: KRB1001W

RoHS  

Contents

Overview	4
Introduction	4
Tap Timer Components	5
Tap Timer Key Features	6
Wi-Fi Hub Components	7
Wi-Fi Hub Features	8
Wi-Fi Hub LED Indicator Status	8
Installation	9
Installing Holman Home	9
Adding your K Connect Wi-Fi Hub to Holman Home	10
Adding K Connect Wi-Fi Hub via AP Mode	12
Batteries	17
Adding your K Connect Tap Timer to the Hub	18
Operation	22
K Connect Home Screen	22
Manual Watering	23
Scheduled Watering	24
Removing your Devices from Holman Home	25
Maintenance	27
Batteries	27
Connection Issues	27
Troubleshooting	28
Warranty	29

Overview

Introduction

The ***K Connect Wi-Fi Hub*** is a device which allows you to connect one ***K Connect Tap Timer*** to have Wi-Fi remote control.

The ***K Connect Wi-Fi Hub*** is for indoor use only and requires a standard 240V power point, with consistent Wi-Fi signal. If the signal is weak or intermittent you may see issues with maintaining remote control capability.

We recommend a maximum of 10 metres between the ***K Connect Wi-Fi Hub*** and the ***K Connect Tap Timer*** for optimal control.

⚠ Please follow the manual and install the batteries prior to connecting the K Connect Tap Timer to the K Connect Wi-Fi Hub

Overview



Tap Timer Components

1. 20/25mm BSP reducing bush
 2. 25mm tap adaptor
 3. **TAP TIMER BUTTON**
 4. Watering LED
 5. 20mm BSP outlet
 6. Battery compartment: requires 3× AAA alkaline batteries only
- ⚠ Do not mix old and new batteries**

Overview

Tap Timer Key Features

- ✔ Set and check irrigation schedules from the **Holman Home** app
- ✔ Manually turn off the water timer using the **TAP TIMER BUTTON**
- ✔ Water with two schedule types: **NORMAL SCHEDULE** and **MISTING**
- ✔ Watering delay options: 24, 48 and 72 hours
- ✔ Low power indicator
- ✔ Built-in filter: Clean this regularly and replace when worn to prolong the life of your **K Connect Tap Timer**
- ✔ Working pressure: 50-800 kPa
- ✔ Maximum flow: 25 L/min
- ✔ Water and dust protection rating: IP54
- ✔ Working temperature: 4°-50°C

⚠ In temperatures below 4°C, your *K Connect* should be removed from the tap and stored indoors to avoid freezing damage

Overview



Wi-Fi Hub Components

7. **Wi-Fi Hub** provisioning button
 8. **Wi-Fi Hub** LED indicator
 9. AC power plug
- i** Requires a standard 240V power point

Overview

Wi-Fi Hub Features

- ✔ Pair with one ***K Connect Tap Timer*** to have Wi-Fi remote control
- ✔ For indoor use only, and must be within Wi-Fi network range
- ✔ For optimum control, maximum of 10 metres between the ***K Connect Wi-Fi Hub*** and the ***K Connect Tap Timer***

⚠ Requires a standard 240V power point, with consistent Wi-Fi signal

⚠ If the signal is weak or intermittent you may see issues with maintaining remote control capability

⚠ 2.4 GHz Wi-Fi connection only

Wi-Fi Hub LED Indicator Status

	Pink/Blue alternating	Provisioning mode
	Blue	Not connected to Wi-Fi
	Pink	Connected to Wi-Fi/Cloud

Installation

Installing Holman Home

1. Download **Holman Home** to your mobile device via the **App Store** or **Google Play**
4. Read our User Agreement and Privacy Policy and tap **AGREE** if you wish to proceed



SCAN FOR MORE INFO

2. Open **Holman Home** on your mobile device
5. Follow the prompts to register a **Holman Home** account with your email address

⚠ Ensure your country details are correct at this stage

- i** You may be prompted to allow notifications—the app can still function if you choose to opt out
3. Tap **SIGN UP**
- i** You may be prompted to allow access to your location. This allows the app to show weather information – it will still function if you choose to opt out

Installation

Adding your K Connect Wi-Fi Hub to Holman Home

1. Plug your **K Connect Wi-Fi Hub** into the power point, it will begin flashing pink and blue alternately 
- i** If solid pink, press and hold the **WI-FI BUTTON** until flashing pink and blue alternately 
- i** If pairing times out – press and hold the button on the **K Connect Wi-Fi Hub** to return to pairing mode
3. Open the **HOME** screen in **Holman Home** and tap  (a) and **ADD DEVICE** (b)




2. Once the device is flashing pink and blue alternately, it is ready to add to **Holman Home**




Installation

Adding your K Connect Wi-Fi Hub to Holman Home


- i** Your device should appear under **DISCOVERING DEVICES** (c)



4. Tap **ADD** (d)
5. On the following **ADD DEVICE** screen, tap **+** (e) to add Wi-Fi Hub



6. Follow the prompts to enter your Wi-Fi credentials
7. After your device is installed, tap **DONE** (f)




Installation

Adding K Connect Wi-Fi Hub via AP Mode

i Use the steps below if your **K Connect Wi-Fi Hub** does not appear under **DISCOVERING DEVICES**

2. Tap **K Connect Wi-Fi Hub** (h), at the top right of the page

1. In the **ADD DEVICE** menu, tap **K-RAIN PRODUCTS** (g)



Installation


Adding K Connect Wi-Fi Hub via AP Mode

3. In the **RESET THE DEVICE** page, tap the top right of the page to see the drop-down menu (i)

4. Select **AP MODE** (j)



5. Tap to **CONFIRM THE LED IS CYCLING** (k), tap **NEXT** (l) to continue




6. Follow the prompts to enter your Wi-Fi credentials

Installation

Adding K Connect Wi-Fi Hub via AP Mode


7. Tap **GO TO CONNECT** (m) to be taken to your Wi-Fi settings menu
8. In the Wi-Fi network list, select the **K Connect Wi-Fi Hub** signal (n), shown below as **Smartlife-BB92**




Installation

Adding K Connect Wi-Fi Hub via AP Mode


- i** For iOS, once the Smartlife network has been ticked, tap **Holman Home** (o) in the top left to exit Settings and return to the app



- i** For Android, once you are **CONNECTED WITHOUT INTERNET** tap the Android Back Button (q) to return to **Holman Home**




- i** For Android, it will show **Internet may not be available**, choose **Connect only this time** (p)



Installation

Adding K Connect Wi-Fi Hub via AP Mode

9. The device connection screen will countdown as the ***K Connect Wi-Fi Hub*** is provisioned



10. Once the device is added, tap **DONE** (r)




Installation

Batteries

1. Unlock the front face by twisting it counter-clockwise (s)



2. Pull out the sealed battery compartment lid (t)



3. Install 3× AAA alkaline batteries (u)

4. Replace the battery compartment lid
5. Replace the front face by ensuring the hooks lock into the body (v) and twist the face clockwise (w)




Installation

Adding your K Connect Tap Timer to the Hub



- i** After being added, the **K Connect Wi-Fi Hub** home page will appear. This can also be accessed via the Wi-Fi hub icon on the home page of **Holman Home**

1. Tap **+ ADD DEVICE** to bring up the menu (x)
2. Tap **SEARCH FOR UNPAIRED DEVICES** (y)




Installation

Adding your K Connect Tap Timer to the Hub

3. Tap **LED IS FLASHING** (z) if the **LED** on your **K Connect Tap Timer** is flashing blue quickly 

- i** If **LED** is not flashing quickly, press and hold the button for about 5 seconds
- i** The **LED** will stop flashing after 1 minute




Installation

Adding your K Connect Tap Timer to the Hub

4. Allow the device to pair



5. Tap **DONE** (A)



Installation

Adding your K Connect Tap Timer to the Hub

6. Tap **DONE** (B)



Operation

K Connect Home Screen


1. Back to **Holman Home**
2. Battery status
3. Watering status
4. **TIME REMAINING**
5. Watering **START/STOP**
6. Settings ⚙️
7. **STATUS**
8. **MANUAL WATERING**
9. **STARTS**
10. **WATERING DELAY** settings



Operation

Manual Watering


1. Tap **MANUAL** to access manual watering controls



2. Tap **MANUAL RUN TIME** (a) to access timer controls

3. Use the scroll wheels (b) to set the **HOURS** and **MINS** for the watering, then tap **SAVE** (c)


4. Tap ► (d) to start watering for the saved duration and ■ (e) to stop watering early as desired



Operation

Scheduled Watering

1. Tap **STARTS** to access scheduled watering controls
2. Tap **SETTINGS** next to the desired **START** (f) to access the scheduling




- i** This allows the following for each **START**:

- Enable/disable **START** (h)
- Set the **START TIME** (i)
- Select watering **DAYS** (j)
- Set the **RUN TIME** (k)

- i** Tap **MISTING** (g) to access timing ideal for misting. These settings also include:

- **ON TIME** (l) for the misting cycle
- **DELAY TIME** (m) for the misting cycle



Operation

Removing your Devices from Holman Home

i Before removing the **K Connect Wi-Fi Hub** from **Holman Home**, please remove paired **K Connect Tap Timer**

1. Tap the 3 dots (n) on the top right of the **K-CONNECT TAP TIMER** square



2. Tap **DISCONNECT FROM K CONNECT Wi-Fi HUB** (o)



3. Tap **CONFIRM** (p) to disconnect




Operation

Removing your Devices from Holman Home

4. Tap the pencil icon in the top right of the **K Connect Wi-Fi Hub** home screen (j)




5. Tap **REMOVE DEVICE** (k)



- i** To remove without resetting to default choose **DISCONNECT** (l)

- i** To reset to factory default, choose **DISCONNECT AND WIPE DATA** (m)



Maintenance

Batteries

- i** Remove batteries from your **K Connect** tap timer during periods of non-use
- ⚠** **Battery leakage can cause corrosion and damage to your K Connect Tap Timer**

Connection Issues

- i** If your **K Connect Tap Timer** shows as disconnected after replacing the batteries, please wait a few minutes for **Holman Home** to update your device status
- i** For additional support with connection issues, please contact our **Customer Service** team



For support email
info@k-rain.com.au or
contact the friendly
Customer Service
team at Holman
Industries on
08 9416 9999

Supplied and Serviced
by Holman Industries

11 Walters Drive, Osborne Park WA 6017



SCAN FOR MORE INFO

Troubleshooting

Question	Answer
<p><i>I am having trouble accessing my K Connect Tap Timer</i></p>	<ul style="list-style-type: none"><li data-bbox="526 430 871 669">☑ When two or more people use the same Holman Home login, the first user to access the Home of the K Connect Tap Timer has control of the device. If another user wants to access the tap timer it will show as OFFLINE until the first user either moves to another Home or exits the Holman Home app<li data-bbox="526 696 864 773">☑ The K Connect Tap Timer and Wi-Fi Hub can not be shared with different Holman Home logins

Warranty

2 Year Replacement Guarantee

Holman Industries offers a 2 year replacement guarantee with this product.

In Australia our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

As well as your statutory rights referred to above and any other rights and remedies you have under any other laws relating to your Holman product, we also provide you with a Holman guarantee.

Holman Industries guarantees this product against defects caused by faulty workmanship and materials for 2 years domestic use from the date of purchase. During this guarantee period Holman Industries will replace any defective product. Packaging and instructions may not be replaced unless faulty.

In the event of a product being replaced during the guarantee period, the guarantee on the replacement product will expire 2 years from the purchase date of the original product, not 2 years from the date of replacement.

To the extent permitted by law, this Holman Replacement Guarantee excludes liability for consequential loss or any other loss or damage caused to property of persons arising from any cause whatsoever. It also excludes defects caused by the product not being used in accordance with instructions, accidental damage, misuse, or being tampered with by unauthorised persons, excludes normal wear and tear and does not cover the cost of claiming under the warranty or transporting the goods to and from the place of purchase.

Should you suspect your product may be defective and need some clarification or advice please contact us directly:

1300 716 188
support@holmanindustries.com.au
11 Walters Drive, Osborne Park 6017 WA

If you are certain your product is defective and is covered by the terms of this warranty, you will need to present your defective product and your purchase receipt as proof of purchase to the place you purchased it from, where the retailer will replace the product for you on our behalf.



We really appreciate having you as a customer and would like to say thank you for choosing us.

We recommend registering your new product on our website. This will ensure we have a copy of your purchase and activate an extended warranty. Keep up to date to with relevant product information and special offers available through our newsletter.



Scan here, or visit
k-rain.com.au/register
for more info